

Деталировка FROSP CRN-45A

| NO. | CODE | Description | NO. | CODE | Description |
|-----|--------|-----------------------|-----|---------|-----------------------|
| 1 | 610120 | BOLT M5X25 | 60 | 630110 | SNAP RING 32 |
| 2 | 321790 | SIDE PROTECTOR | 61 | 420540 | FILTER |
| 3 | 421160 | SIDE BAFFLE | 62 | 510590 | O-RING 43.7X2.65 |
| 4 | 321780 | BOLT(Loctite) | 63 | 110410 | END CAP |
| 5 | 421150 | EXHAUST COVER | 64 | 610120 | BOLT M5X25 |
| 6 | 321590 | EXHAUST FILTER | 65 | 323220 | DOWEL PIN |
| 7 | 410550 | WASHER | 66 | 420590 | TRIGGER BRACKET |
| 8 | 110400 | CYLINDER CAP | 67 | 620370 | SPRING |
| 9 | 620770 | COM. SPRING | 68 | 110190 | ADJUST BUTTON |
| 10 | 410540 | PISTON STOP | 69 | 320880 | CONTACT PLATE |
| 11 | 421140 | HEAD VALVE PISTON | 70 | 420580 | TRIGGER |
| 12 | 510910 | O-RING 30X2 | 71 | 510580 | O-RING 42.5X1.5 |
| 13 | 510920 | O-RING 42X2.65 | 72 | 610100 | BOLT M5X20(Loctite) |
| 14 | 410530 | CYLINDER SLEEVE | 73 | 620790 | CHECK PAWL SPRING (A) |
| 15 | 520270 | GASKET | 74 | 210550 | CHECK PAWL (A) |
| 16 | 410520 | BUMPER | 75 | 210540 | CHECK PAWL (B) |
| 17 | 321760 | DRIVER BLADE(Loctite) | 76 | 620780 | CHECK PAWL SPRING (B) |
| 18 | 421130 | PISTON RING | 77 | 322200 | DOOR PIN |
| 19 | 310360 | PISTON | 78 | 210530 | DOOR |
| 20 | 421120 | CYLINDER RING | 79 | 321900 | CHECK PAWL PIN |
| 21 | 520260 | CYLINDER SEAL | 80 | 640060 | ROLL PIN 3X10 |
| 22 | 510930 | O-RING 42.5X1.8 | 81 | 620840 | LATCH SPRING |
| 23 | 510940 | O-RING 58X2.65 | 82 | 210590 | LATCH |
| 24 | 310350 | CYLINDER | 83 | 610060 | BOLT M5X10 |
| 25 | 421110 | CYLINDER COLLAR | 84 | 321890 | WASHER |
| 26 | 421100 | GUARD COVER | 85 | 610870 | BOLT M6X10(Loctite) |
| 27 | 421090 | SAFETY GUIDE | 86 | 210580 | SAFETY LOWER |
| 28 | 630090 | SNAP RING 4 | 87 | 321880 | SAFETY |
| 29 | 321750 | ADJUSTER | 88 | 210570 | NAIL GUIDE |
| 30 | 510140 | O-RING 5.15X1.8 | 89 | 620830 | SPRING |
| 31 | 421080 | ADJUSTER DIAL | 90 | 321870 | STEP PIN |
| 32 | 640020 | ROLL PIN 2.5X10 | 91 | 510050 | O-RING 2.8X1.8 |
| 33 | 321740 | SAFETY UPPER | 92 | 210560 | NOSE |
| 34 | 620670 | SPRING | 93 | 510280 | O-RING 9X2 |
| 35 | 421070 | SAFETY UPPER GUIDE | 94 | 510400 | O-RING 18X2 |
| 36 | 510950 | O-RING 3.55X1.8 | 95 | 321860 | FEED PISTON |
| 37 | 210520 | FEED PAWL | 96 | 620820 | FEED PISTON SPRING |
| 38 | 420170 | PIN CAP (A) | 97 | 410560 | FEED PISTON BUMPER |
| 39 | 620760 | FEED SPRING | 98 | 321850 | FEED PISTON CAP |
| 40 | 321820 | FEED PAWL PIN | 99 | 610020 | BOLT M4X8 |
| 41 | 512080 | O-RING 5.5x2 | 100 | 321840 | SCALE SHIELD |
| 42 | 330010 | TRIGGER VALVE BUSHING | 101 | 421230 | SCALE SLIDER |
| 43 | 510220 | O-RING 6.7X1.8 | 102 | 620810 | SPRING |
| 44 | 510240 | O-RING 8.6x1.9 | 103 | 421220 | SCALE BRACKET |
| 45 | 620050 | TRIGGER VALVE SPRING | 104 | 610340 | HEX BOLT |
| 46 | 320110 | TRIGGER STEM | 105 | 322180 | SPRING HOLDER (A) |
| 47 | 510030 | O-RING 2.5X1.4 | 106 | 640160 | ROLL PIN 3X25 |
| 48 | 420080 | TRIGGER VALVE CAP | 107 | 421210 | MAGAZINE |
| 49 | 512070 | O-RING 15.8X1.9 | 108 | 421200 | MAGAZINE POST |
| 50 | 420090 | TRIGGER VALVE CAGE | 109 | 620800 | MAGAZINE SPRING |
| 51 | 510410 | O-RING 18.3X2.65 | 110 | 421190 | NAIL SUPPORT PLATE |
| 52 | 640250 | STRAIGHT PIN B3X15 | 111 | 421180 | SPRING HOLDER (B) |
| 53 | 620740 | SPRING | 112 | 421170 | MAGAZINE COVER |
| 54 | 640180 | ROLL PIN 3X30 | 113 | 510070 | O-RING 3.15X1.5 |
| 55 | 110420 | BODY | 114 | 321830 | MAGAZINE PIN |
| 56 | 410460 | HANDLE GRIP | | | |
| 57 | 321810 | STEP PIN | | | |
| 58 | 420950 | PIN CAP | P1 | D321761 | DRIVER UNIT |
| 59 | 640150 | ROLL PIN 3X24 | P2 | T420091 | TRIGGER VALVE |

