



Chart Ref	Spare part code	Description	Status	Previous Part Code 1	Previous Part Code 2
1	<a href="#">174064</a>	SCREW,SHCS,M5x0.8x18	active		
2	<a href="#">P2020000140</a>	CAP	active		
3	<a href="#">S06A013800</a>	O-RING	active		
4	<a href="#">P2040000300</a>	VALVE SEAT	active		

Chart Ref	Spare part code	Description	Status	Previous Part Code 1	Previous Part Code 2
5	<a href="#">P202000300</a>	GASKET	active		
6	<a href="#">P2042000500</a>	ASSEMBLY,CYLINDER	active		
7	<a href="#">S06Z003200</a>	O-RING	active		
8	<a href="#">S06Z002700</a>	SEAL	active		
9	<a href="#">P2040000800</a>	BUMPER,VALVE	active		
10	<a href="#">P2042000700</a>	VALVE	active		
11	<a href="#">S06A013100</a>	O-RING	active		
12	<a href="#">S06A022300</a>	O-RING	active		
13	<a href="#">G0201600</a>	ASSEMBLY,DRIVER/PISTON	active		
14	<a href="#">P2040001300</a>	BUMPER	active		
15	<a href="#">S06A014300</a>	SEAL	active		
16	<a href="#">P2020000232</a>	FRAME	active		
17	<a href="#">P2045203762</a>	WASHER	active		
18	<a href="#">P2045201762</a>	SPRING	active		
19	<a href="#">G3200200</a>	NOSE, PN100	active		
20	<a href="#">P2040003100</a>	MAGNET	active		
21	<a href="#">P2040002900</a>	RETAINER,MAGNET	active		
22	<a href="#">S06S002000</a>	SEAL	active		
23	<a href="#">P2045201862</a>	GUIDE	active		