

Детализировка и лист запасных частей FROSP CN-80

TIEM NO.	PART NAME	Qty	TIEM NO.	PART NAME	Qty
1	Hex bolt M8*20	1	51	Pin 3*16	2
2	Cylinder head bushing	1	52	Trigger	1
4	Exhaust cover	1	53	Skateboard frame	1
5	Cylinder cover bumper	1	54	Outer bumper	1
6	Cylinder cap plug	1	55	Inner bumper	1
7	Hex bolt M6*35	4	56	Sealing plug	1
8	Safty frame	2	57	Active cover shaft pinlever	1
9	Cylinder cap	1	58	O ring 53.5*1.5	1
10	Cylinder head gasket	1	59	O ring 4.2*1.6	1
11	Spring seat washer	1	60	Nose	1
12	Spring seat	1	61	Hex bolt M8*30	4
13	Compressed spring	1	62	Hex bolt M6*40	2
14	O ring 41.7*3	1	63	Trigger piece	1
15	Valve gasket	1	64	Trigger piece spring	1
16	Swift valve	1	65	Cover plate	1
17	O ring 56.8*3	1	66	Pin sleeve	2
18	O ring 43*4.9	1	67	Rubber stopper	1
19	Piston assembly	1	68	Gun head protective film	1
20	Cylinder seal	1	69	Shaft pin	1
21	Cylinder	1	70	Pin 3*12	1
22	O ring 56*3.1	1	71	Nail block spring	1
23	Collar	1	72	Nail stopper	1
24	O ring 88*3	1	73	Safety frame spring	1
25	O ring 56*5.7	1	74	Safety Yoke	1
26	Gun body	1	75	Send nail claw	1
29	Rubber grip	1	76	Send nail claw spring	1
30	O ring 56*2.65	1	77	Piston pin	1
31	End cap	1	79	Nail feed piston	1
33	Pin 3*32	1	80	O ring 20.4*2.4	1
34	Pin 3*25	3	81	Nail bumper	1
35	Pin 3*20	1	82	Nail send spring	1
36	O ring 14.5*1.8	1	83	Piston spring seat	1
37	Valve seat	1	84	Retaining ring	1
38	O ring 16*1.6	1	86	Spring holder	2
39	Valve sleeve	1	87	Extension spring	1
40	O ring 6.1*1.8	1	88	Nail feed tray	1
41	O ring 6.4*2	1	89	Nail length adjustment seat	1
42	O ring 9*1.8	1	91	Adjust holder seal	1
43	Trigger spring	1	93	Plain washer	2
44	Trigger lever	1	94	Seal cap	1
45	O ring 2.4*1.6	2	95	Nose cap	1
46	O ring 20*1.8	1	97	Hex bolt M6	2
47	Trigger seat	1	98	O ring 56*2.8	1
50	Hook stop lever	1	3, 78	O ring 9.9*2.4	2
			85, 90, 92	Nail house assembly	1

