


Детализировка и лист запасных частей к гайковерту FROSP ПГ-254



No.	Name	Q'ty	No.	Name	Q'ty
1	hex screw	8	22	trigger	1
2	spring gasket	8	23	pin	1
3	hammer case	1	24	inlet gasket	1
4	anvil bushing	1	25	rubber gasket	1
5	circlip	1	26	air inlet valve	1
6	o ring	1	27	spring	1
7	anvil	1	28	air inlet screen	1
8	hammer	2	29	air inlet	1
9	hammer cage	1	30	o ring	1
10	hammer pin	2	31	plastic cover	1
11	gasket	1	32	handle	1
12	bearing	1	33	throttle bushing	1
13	front end plate	1	34	steel ball	1
14	vane	6	35	spring	1
15	rotor	1	36	throttle core	1
16	pin	2	37	o ring	1
17	cylinder	1	38	button	1
18	pin	1	39	gasket	1
19	rear end plate	1	40	screw	1
20	bearing	1	41	back cover	1
21	gasket	1	42	gasket	1