

Parts List and Drawing

CN90 PARTS LIST

NO.	CODE	Description	NO.	CODE	Description
1	610630	BOLT M8X25 (Loctite)	56	510320	O-RING 10X2.65
2	320480	EXHAUST COVER	57	110110	BODY
3	630070	SPRING WASHER 6	58	510090	O-RING 4X1.5
4	610240	BOLT M6X35	59	420080	TRIGGER VALVE CAP
5	320470	SIDE PROTECTOR	60	320110	TRIGGER STEM
6	110120	CYLINDER CAP	61	510030	O-RING 2.5X1.4
7	520120	GASKET	62	620050	TRIGGER VALVE SPRING
8	320460	RING	63	330010	TRIGGER VALVE BUSHING
9	420370	PISTON STOP	64	510240	O-RING 8.6X1.9
10	620010	COMPRESSION SPRING	65	510180	O-RING 5.8X1.9
11	510570	O-RING 41.2X3.55	66	510210	O-RING 6.3X1.8
12	510730	O-RING 56X2.65	67	640250	STRAIGHT PIN B3X15
13	310490	HEAD VALVE PISTON	68	420090	TRIGGER VALVE CAGE
15	510970	O-RING 44X4.5	69	510410	O-RING 18.3X2.65
16	310140	PISTON	70	510380	O-RING 16X1.8
18	323110	DRIVER BLADE(Loctite)	71	320620	SAFETY BRACKET
19	420350	CYLINDER SEALING RING	73	640190	ROLL PIN 3X32
20	310110	CYLINDER	74	640160	ROLL PIN 3X25
21	510730	O-RING 56X2.65	75	410140	HANDLE GRIP
22	520110	CYLINDER SEAL	76	320570	TRIGGER
23	420340	CYLINDER RING	77	320560	CONTACT PLATE
24	511660	O-RING 84x3.05	78	640340	ROLL PIN 3X16
25	410130	BUMPER (A)	79	420110	FILTER
26	410120	BUMPER (B)	80	110030	END CAP
27	610330	NUT M6 (Nylock)	81	510760	O-RING 58X3.55
28	420180	GUARD COVER	82	630020	SNAP RING 52
29	323290	SAFETY	83	420190	MAGAZINE COVER
30	620100	SAFETY SPRING	84	420520	SPRING HOLDER (A)
31	320200	CHECK PAWL PIN	85	420210	NAIL SUPPORT PLATE
32	210050	DOOR	86	620650	MAGAZINE SPRING
33	640080	ROLL PIN 3X12	87	420230	MAGAZINE POST
34	620240	LATCH SPRING	88	630030	WASHER
35	210070	LATCH	89	420240	SPRING HOLDER (B)
36	420160	PIN CAP (B)	90	320260	MAGAZINE PIN
37	210060	CHECK PAWL	91	421290	MAGAZINE
38	620070	CHECK PAWL SPRING	92	410160	PLASTIC WASHER
39	610300	BOLT M8X25(Loctite)	93	610250	BOLT M6X40
40	210660	NOSE	94	324530	WASHER
41	510670	O-RING 50X1.8	95	420250	DUST COVER
42	420150	PIN PLUG	96	410060	RUBBER BUTTON
43	320190	DOOR PIN	97	630290	SNAP RING 17
44	640340	ROLL PIN 3X16	98	620120	FEED PISTON SPRING (A)
45	320210	FEED PAWL PIN	99	320280	SPRING GUIDE
46	620610	FEED SPRING	100	322610	PLASTIC WASHER
47	210080	FEED PAWL	102	410880	STRAIGHT PIN CAP
48	320290	FEED PISTON	103	323150	STRAIGHT PIN
49	620130	FEED PISTON SPRING (B)	104	410650	RUBBER PLUG
50	410150	FEED PISTON BUMPER	105	320610	HEAD VALVE WASHER
51	320590	FEED PISTON CAP	106	511380	O-RING 10.6X2.65
52	630050	SNAP RING 26	107	324520	TRIGGER SLEEVE
53	610240	BOLT M6X35			
54	420170	PIN CAP (A)	P1	D323111	DRIVER UNIT
55	510430	O-RING 20X2.65	P2	T420091	TRIGGER VALVE

CN90

